

## Troubleshoot - Blowing dust

If dust blows out from the bottom, it is because dusted air does not flow enough through filters. It is a simple scientific fact. Not enough air flow is due to either/both the clogged (or dense filters) or/and a weak fan motors. Usually 98% is from the former case - filters.

### 1. Clogged filter

Filter should be cleaned every day and replaced every 2 months at least.

### 2. Dense or thick filter

BAUUSA filters are 2 layers - inner and outer filters (Picture).



Outer one is made of carbon activated filter which is good for reducing smell and collecting dust. Inner filter is for not only collecting dust but also controlling air flow. Suction power is directly related to the filter thickness and various gel or acrylic ingredients. If filters seem to be too thick or dense for air flow, just take out the inner filter for the better air passage.

### 3. Air diffuser

Air diffuser is for diverting sucked air with dust into side of filter rather than ceiling of the filter in order to prevent piled dust falling down from the ceiling. But it might be the blockage for air flow. If one layer of filter does not help suction power, then remove the air diffuser.

### 4. Weak fan motor

If fan motor seems weak, it should be changed.

Please try 1 - 3 above.

If the symptom still exists, please let us know.